Subject: #1287, RPR2006C v2.3.2 is slower then v1.0.8

From: Jeffrey Westgeest <jewe@dare.nl>

Date: 04/20/2016 06:18 AM

To: "kuiper@jpl.nasa.gov" <kuiper@jpl.nasa.gov>

CC: Antoine van Peer <anpe@dare.nl>, "Franco, Manuel" <Manuel.M.Franco@jpl.nasa.gov>,

"Teitelbaum, Larry" <Lawrence.Teitelbaum@jpl.nasa.gov>

Dear Mr. Kuiper,

My name is Jeffrey Westgeest and I am one of the senior developers at DARE!! Instruments.

I have looked at the reported item with the RadiPower. (#1287, RPR2006C v2.3.2 is slower then v1.0.8)

At this moment I have the impression that your reported item is related to the behavior of the filter setting.

I have done several measurements with the auto and fixed filter settings.

The used python script for testing is attached.

I have used Debian GNU/Linux 8.4 (jessie) 64 bits as testing machine.

The results of my measurements:

Signal generator output: -50 dBm

Filter: AUTO Samples: 1000

Measuring: -50.89 dBm

Duration(Sec): 164.943696022

Signal generator output: -40 dBm

Filter: AUTO Samples: 1000

Measuring: -41.11 dBm

Duration(Sec): 104.533071995

Signal generator output: -30 dBm

Filter: AUTO Samples: 1000

Measuring: -31.02 dBm

Duration(Sec): 44.7287838459

Signal generator output: -20 dBm

Filter: AUTO Samples: 1000

Measuring: -20.78 dBm

Duration(Sec): 23.5713908672

Signal generator output: -10 dBm

Filter: AUTO Samples: 1000

Measuring: -10.67 dBm

Duration(Sec): 17.5558629036

Signal generator output: 0 dBm

Filter: AUTO Samples: 1000

Measuring: -10.67 dBm

Duration(Sec): 17.5558629036

Signal generator output: -50 dBm

Filter: 7

Samples: 1000

Measuring: -50.88 dBm

Duration(Sec): 158.494415998

Signal generator output: -50 dBm

Filter: 6

Samples: 1000

Measuring: -50.87 dBm

Duration(Sec): 98.3870871067

Signal generator output: -50 dBm

Filter: 5

Samples: 1000

Measuring: -50.86 dBm

Duration(Sec): 38.2345271111

Signal generator output: -50 dBm

Filter: 4

Samples: 1000

Measuring: -50.87 dBm

Duration(Sec): 17.1574699879

Signal generator output: -50 dBm

Filter: 3

Samples: 1000

Measuring: -50.86 dBm

Duration(Sec): 11.1494948864

Signal generator output: -50 dBm

Filter: 2

Samples: 1000

Measuring: -50.90 dBm

Duration(Sec): 9.04163908958

Signal generator output: -50 dBm

Filter: 1

Samples: 1000

Measuring: -50.87 dBm

Duration(Sec): 8.44735884666

Signal generator output: 0 dBm

Filter: 1

Samples: 1000

Measuring: -0.49 dBm

Duration(Sec): 8.42022705078

Signal generator output: 0 dBm

Filter: 7

Samples: 1000

Measuring: -0.47 dBm

Duration(Sec): 151.038294077

In your initial e-mail you spoke about reaching a bit more than 100 readings per second. In document bookThree570-572, there is a screen shot(Fig. 1.61) with the auto filter selected.

Based on my measurements, I have to conclude that you probable have performed the initial measurements with filter 1 or 2.

With the auto filter and 0 dBm you still need 17.5 mSec (57 Hz) for a measurement.

Can you verify that with filter 2 you get the reading speed that you need?

--

Best regards,

Jeffrey Westgeest Senior Software Engineer

D.A.R.E!! Instruments Vijzelmolenlaan 7 NL-3447 GX Woerden The Netherlands

tel: + 31 348 48 11 44 fax: + 31 348 48 06 52 e-mail: jewe@dare.nl internet: http://www.dare.nl

~ Measure the Difference!! ~

The information transmitted is intended only for the person or entity to which it is addressed and may contain confidential and/or privileged material. Any review, retransmission, dissemination or other use of, or taking of any action in reliance upon, this information by persons or entities other than the intended recipient is prohibited. If you received this in error, please contact the sender and delete the material from any computer.

```
-speed.py
# Test program for RPR2006C speed measurement.
import serial
from timeit import default timer as timer
def readlineCR(port):
   rv = ""
   while True:
        ch = port.read()
        if ch=='\n' or ch=='':
            return rv
        else:
            rv += ch
port = serial.Serial("/dev/ttyUSB0", baudrate=115200, timeout=3.0)
#Getting the current filter setting
port.write("Filter?\n")
rcv = readlineCR(port)
print "Filter:", rcv
# time the measurement
start = timer()
for x in range(0, 1000):
        port.write("POWER?\n")
        rcv = readlineCR(port)
end = timer()
print "Samples:", x+1
#print the last measurement, to ensure that the power is measuring what we
are expecting.
print "Measuring:", rcv
#print the test time
print "Duration(Sec):", (end - start)
-Attachments:
                                                                      763 bytes
 speed.py
```